













GLYPHOSATE DETAILED FLOWCHART

<p>1.</p>  <p>Remove upper rack from magnetic base. Label test tubes for Standards, Control, and Samples.</p> <table border="1"> <thead> <tr> <th>Tube #</th> <th>Content</th> </tr> </thead> <tbody> <tr> <td>1, 2</td> <td>Diluent/Zero Standard 0 ppb</td> </tr> <tr> <td>3, 4</td> <td>Standard 1, 0.15 ppb</td> </tr> <tr> <td>5, 6</td> <td>Standard 2, 1.0 ppb</td> </tr> <tr> <td>7, 8</td> <td>Standard 3, 5.0 ppb</td> </tr> <tr> <td>9,10</td> <td>Control</td> </tr> <tr> <td>11,12</td> <td>Sample 1</td> </tr> <tr> <td>13,14</td> <td>Sample 2</td> </tr> <tr> <td>15,16</td> <td>Sample 3</td> </tr> </tbody> </table> <p>Add 300 μL of either Derivatized Standards, Control or Samples to the bottom of each test tube by inserting the pipette tip all the way into the bottom of the tube without touching the sides of the tube.</p> 	Tube #	Content	1, 2	Diluent/Zero Standard 0 ppb	3, 4	Standard 1, 0.15 ppb	5, 6	Standard 2, 1.0 ppb	7, 8	Standard 3, 5.0 ppb	9,10	Control	11,12	Sample 1	13,14	Sample 2	15,16	Sample 3	<p>7.</p>  <p>Do not separate upper rack from lower base. Using a smooth motion, invert the combined rack assembly over a sink and pour out the tube contents; keep inverted and gently blot the test tube rims on several layers of paper toweling.</p>
Tube #	Content																		
1, 2	Diluent/Zero Standard 0 ppb																		
3, 4	Standard 1, 0.15 ppb																		
5, 6	Standard 2, 1.0 ppb																		
7, 8	Standard 3, 5.0 ppb																		
9,10	Control																		
11,12	Sample 1																		
13,14	Sample 2																		
15,16	Sample 3																		
<p>2.</p>  <p>Add 500 μL of thoroughly mixed Glyphosate Antibody Coupled Magnetic Particles down the inside wall of each tube by using the technique described in Box 2. <i>Vortex</i> for 1 to 2 seconds (at low speed to minimize foaming).</p>	<p>8.</p>  <p>Add 1 mL of Washing Solution down the inside wall of each tube by using the technique described in Box 2. <i>Wait 2 minutes</i>. Using a smooth motion, invert the combined rack assembly over a sink and pour out the tube contents: keep inverted and gently blot the test tube rims on several layers of paper toweling. Repeat this step two times.</p> 																		
<p>3.</p>  <p>React 30 minutes at room temperature (15° - 30°C).</p>	<p>9.</p>  <p>Lift the upper rack (with its tubes) off the magnetic base; add 500 μL of Color Reagent down the inside wall of each tube by using the technique described in Box 2. <i>Vortex</i> for 1 to 2 seconds (at low speed to minimize foaming).</p> 																		
<p>4.</p>  <p>Add 250 μL of Glyphosate Enzyme Conjugate down the inside wall of each tube by aiming the pipet tip 1/4" to 1/2" below the tube rim without touching the rim or tube wall with the pipet tip; deliver liquid gently.</p>	<p>10.</p>  <p>React for 20 minutes at room temperature (15°- 30° C). During this period, add 1 mL of Washing Solution into a clean tube for use as an instrument blank in Step 10.</p>																		
<p>5.</p>  <p>React 30 minutes at room temperature (15° - 30°C).</p>	<p>11.</p>  <p>Add 500 μL of Stopping Solution down the inside wall of each tube by using the technique previously described. <i>Read</i> results at 450 nm within 15 minutes after adding the Stopping Solution. <i>Multiply</i> results of samples by the appropriate dilution factor (if any).</p> <p>[Safety Caution: Stopping Solution contains diluted sulfuric acid.]</p> 																		
<p>6.</p>  <p>Combine the upper rack with the magnetic base; press all tubes into base; allow 2 minutes for the particles to separate.</p>																			

For Ordering or Technical Assistance Contact:
ABRAXIS, LLC 54 Steamwhistle Drive, Warminster, PA 18974
Phone: 215-357-3911 Fax: 215-357-5232
Web: www.abraxiskits.com

Glyphosate Magnetic Particle Kit Part # 500080, 120 Test

GLYPHOSATE CONCISE FLOWCHART

<p>1.</p>  <p>Separate the rack.</p>  <p>Add 300 μL of either Derivatized Standards, Control or Samples to the bottom of each test tube.</p>	<p>7.</p>  <p>Invert the combined rack. Blot gently.</p>
<p>2.</p>  <p>Add 500 μL of mixed Magnetic Particles to each test tube.</p> <p>Vortex.</p>	<p>8.</p>  <p>Add 1 mL of Washing Solution.</p> <p>Wait 2 minutes.</p> <p>Invert the combined rack.</p> <p>Blot gently.</p> <p>Repeat this step two times</p> 
<p>3.</p>  <p>Incubate for 30 minutes.</p>	<p>9.</p>  <p>Separate the rack.</p> <p>Add 500 μL of Color Reagent to each test tube.</p> <p>Vortex.</p> 
<p>4.</p>  <p>Add 250 μL of Enzyme Conjugate to each test tube.</p> <p>Vortex.</p>	<p>10.</p>  <p>Incubate for 20 minutes.</p> <p>Prepare blank.</p>
<p>5.</p>  <p>Incubate for 30 minutes.</p>	<p>11.</p>  <p>Add 500 μL of Stopping Solution to each test tube.</p> <p>Read OD 450</p> 
<p>6.</p>  <p>Combine the rack and magnetic base.</p> <p>Seat all tubes.</p> <p>Wait 2 minutes.</p>	

For Ordering or Technical Assistance Contact:
 ABRAXIS, LLC 54 Steamwhistle Drive, Warminster, PA 18974
 Phone: 215-357-3911 Fax: 215-357-5232
 Web: www.abraxiskits.com

Glyphosate Magnetic Particle Kit Part # 500080, 120 Test

