

# Melamine Strip Test (Milk)

## 1. Collect Sample



SAMPLE

Collect 1 to 2 ml of sample.


## 2. Add Buffer

Add 3 drops of sample buffer to the conical flip-top tube.




## 3. Add Sample

Using the pipette provided, add 3 drops of SAMPLE to the conical, flip-top tube.



## 4. Shake



Close the conical, flip-top tube and shake for 10-20 seconds.

## 5. Test


Insert test strip into conical, flip-top tube with arrow pointing down.

Incubate for 10 minutes.




## 6. Dry

Remove test strip. Lay flat and allow to continue developing for 5 minutes.



## 7. Interpret



CONTROL LINE	TEST LINE	INTERPRETATION
NO CONTROL LINE PRESENT	NO TEST LINE PRESENT	INVALID RESULT
CONTROL LINE PRESENT	TEST LINE OF EQUAL OR GREATER INTENSITY	< 250 ppb
CONTROL LINE PRESENT	MODERATE INTENSITY TEST LINE (LESS INTENSITY THAN CONTROL LINE) OR NO TEST LINE PRESENT	> 250 ppb

For Ordering or Technical Assistance Contact:  
 ABRAXIS, LLC 54 Steamwhistle Drive, Warminster, PA 18974  
 Phone: 215-357-3911 Fax: 215-357-5232 www.abraxiskits.com

50 Test: PN 50005SM