


Glyphosate Strip Test


PN 500098 (5T), 500095 (20T)

1. Collect Sample/Extract




Collect sample or extract.

2. Transfer



Using the graduated pipette provided, transfer 1 mL of SAMPLE to the mixing vial.


3. Mix



Mix for 30 seconds.

4. Add Mixture to Derivatization Vial

Using the same graduated pipette, add the entire contents (2 mL) of mixture to derivatization vial.




Cap and shake for 30 seconds.

Incubate for 10 min.

(The Derivatization Vial contains a small amount of liquid reagent.)

5. Transfer


Using the transfer pipette provided, add 6 drops of derivatized sample to the conical flip-top tube.



(The conical flip-top tube contains dried reagents.)

6. Shake and incubate

Close the conical flip-top tube and shake for 30 seconds.




Incubate for 10 minutes.

(Dried reagents will dissolve, turning the sample purple.)

7. Test


Insert test strip into conical flip-top tube with arrow pointing down (sample pad down).




Incubate for 10 minutes.

8. Dry

Remove test strip. Lay flat and allow to continue developing for 5-10 minutes.



9. Interpret



CONTROL LINE	TEST LINE	INTERPRETATION
NO CONTROL LINE PRESENT	NO TEST LINE PRESENT	INVALID RESULT
CONTROL LINE PRESENT	VERY FAINT TEST LINE OR NO TEST LINE PRESENT	>100 ppb
CONTROL LINE PRESENT	MODERATE INTENSITY TEST LINE PRESENT	BETWEEN 2.5 ppb AND 100 ppb

For Ordering or Technical Assistance Contact:
 ABRAXIS, INC. 124 Railroad Drive, Warminster, PA 18974 Phone: 215-357-3911 Fax: 215-357-5232 www.abraxiskits.com